


## Easy-Trim Ridge F Hip Accessory Kit

5 x Hip Trays, 26 x Short Leg Ratchet Clips,  
20 x Long Hip Clips, 20 x Short Hip Clips

# easy-trim<sup>®</sup> Ridge F

### Hip Accessory Kit Contents:



### PLEASE NOTE:

Our Hip Accessory Kit is to be used in conjunction with our own 6m Ridge F Kit



Before installation, ensure you have a 6m ridge kit and that all kit components are present and correct in number.



Tel: +44 (0) 845 034 6008

e: [enquiries@easy-trim.co.uk](mailto:enquiries@easy-trim.co.uk)

f: +44 (0) 845 034 6010

Unit 12B Metcalf Drive  
Altham Industrial Estate | Altham  
Lancashire | BB5 5TU | England  
w: [www.easy-trim.co.uk](http://www.easy-trim.co.uk)

find us:



## Easy-Trim Ridge F Hip Kit Step-by-Step instructions

# easy-trim Ridge F



**1** Lay underlay as normal ensuring that the underlay overlaps the other side by 150mm min, and install tiling battens to the hip rafter or to noggins nailed to the hip rafter.



**2** Build up the hip batten on the hip rafter, to a height such that the hip tray overlaps the tiles on both sides and secure with nails.



**3** Lay tiles as normal, ensure neatly cut tiles along the hip battens are no more than 30mm from the battens, and secured using the long and short hip clips provided. Nail the long hip clip to the batten through the holes provided, and then slide the cut tile into the clip below. Clip the short hip clip to the top end of the cut tile, attaching it to the adjoining tile at the interlock.



**4** Roll out the Easy-Ridge F roll centrally across the entire length of the ridge batten, using the white spine of the roll as a guide over the ridge batten. Secure the roll by nailing through the white spine using corrosion resistant nails provided. All joints in the ridge roll must be overlapped by 75mm min. Leave a 75mm long strip of the roll at each end of the hip.




**5** Remove the release paper from the butyl adhesive strip on the underside of each edge of the roll, and firmly press onto the clean, dry tile on both sides (avoid crushing the corrugations). Ensure the rolls overlap at the hip abutment, and at the eaves carefully tuck back and stick behind the tiles



**6** Lay the hip trays centrally over the hip roll, overlapping the next tray by approximately 75mm and secure with nails.



**7** Insert the Long and two short ratchet clips loosely into the middle and side slots respectively on the union. Lay the block end hip tile on the roll starting at the eaves, mechanically fix with screw and washer, and slide the union into the open end of the tile. Slide the next hip tile into the open end of the union and press all three clips firmly in place. Secure the union with the screws provided, through the long ratchet clips. Any protruding end of the union can be snapped off or folded behind the union.



**8** Cut the tiles to form a neat mitre junction at the ridge hip junction. Drill a hole near the mitre and mechanically fix each tile with a screw to the batten. Seal openings in the cut tiles with a roofing grade mastic sealants.